

Instructions to assemble skid frame

Four Us[®]

Skid frame:

Be aware that there is a right and a left side skid frame



Tools used in the manual:

Umbraco key, size 5

Correct bit screw for the wooden screw



- 1 Lay the couch on the back to access the bottom. Preferable by two people laying it on a clean surface, for protection of the couch.



2 Screw the screws loosely in the 4 top inserts, using fingers only.



3 Screw the screws loosely in the 4 bottom inserts, using fingers only. Use the other hand to guide the skid frame into correct position for the inserts.



4 Tighten the screws with a size 5 Umbraco key.



- 5 Use a drill with the correct bit for the wooden screws to screw the wooden screws tightly into position.



- 6 Repeat this procedure for the other side of the couch, with the skid frame for the other side.



7 To protect the skid frame, be two people to lift the couch up to the upright position. Only set the couch down, when it can be placed on the plastic ferrules.

